

型式:TE4-20

負荷調整ダイヤル	1	2	3	4	5	6	7
60(定格)	3	5	7	10	12	15	20
20	1	1	1	1	2	2	3
30	1	1	2	3	3	4	6
40	1	2	3	4	6	7	10
50	2	3	4	6	9	11	15
60	2	4	6	9	12	16	21
70	3	5	8	12	16	22	29
80	4	6	10	15	21	28	37

単位(W)

型式:TE4-70

負荷調整ダイヤル	1	2	3	4	5	6	7
60(定格)	20	30	40	50	60	65	70
20	3	4	5	6	7	7	8
30	6	8	11	13	15	17	18
40	9	14	19	22	26	28	31
50	14	21	28	35	40	44	48
60	19	29	39	48	55	62	68
70	25	39	52	64	74	82	90
80	32	51	68	83	96	105	115

単位(W)